

Icon	Name	Default Time	Adjustable Time	Default Temperature	Adjustable Temperature	Pressure	Delayed Start 10 min – 12 h	Keep Warm Up to 24 h	Lid Closed Locked	Lid Closed Unlocked	Lid Open
	Stew	30 min	1 min – 2 h	114°C		70 kPa	Yes	Yes	Yes		
	Soup	12 min	1 min – 2 h	114°C		70 kPa	Yes	Yes	Yes		
	Brown Stir Fry	20 min	1 min – 1 h	160°C	100-160°C						Yes
	Steam	10 min	1 min – 2 h	114°C		70 kPa	Yes	Yes	Yes		
	Bake	40 min	1 min – 2 h	160°C	100-160°C		Yes	Yes		Yes	
	Slow Cook Sous-Vide	4 h	30 min – 12 h	85°C	55-95°C		Yes		Yes	Yes	
	Rice	12 min	1 min – 2 h	114°C		70 kPa	Yes	Yes	Yes		
	Yogurt Bread Rise	8 h	30 min – 12 h	30°C	22-40°C				Yes	Yes	
	Oatmeal Porridge	15 min	1 min – 2 h	100°C			Yes	Yes		Yes	
	Manual Mode	30 min	1 min – 4 h	80°C	70-160°C			Yes	Yes	Yes	Yes